



# Dyson Cyclone V10

## How to clean the filter



Filter must be washed at least every month.

Dry the filter under the sun over 24 hours before setting



## How to clear the bin

Close the bin to click into place




## How to clean the roller cleaner head


異物の取り除き方 - ソフトローラークリーナーヘッド




1




2



3



4



5



