

**IRIS OYAMA
RC-MA50AZ-B**

Change menu


- >Rinse-free rice
- >White rice
- >Takikomi gohan
- >Congee
- >Brown rice
- >Stew/Steam

- Eco mode
- Quick cooking

Change type of rice

- >Koshihikari
- >Akitakomachi
- >Tsuyahime
- >Yumebirika
- >Hitomebore
- >Hinohikari

Keep warm lamp



Keep Warm
Cancel

Timer

Hour | Minute

Cook

To cook rice:

1. Select the suitable type of rice (not necessary if you use a type of rice other than those from the list).
2. Select suitable cooking menu.
3. Press 'Cook'

To use timer function:

1. Press the 'Timer' button.
2. Select time using the 'Hour' and 'Minute' buttons.
3. Select suitable type of rice and cooking menu.

Please clean the inside of the rice cooker regularly to ensure the rice cooker works properly and lasts longer.